

## **FIRMWARE UPDATE INSTRUCTION + UPDATE HISTORY**

*To assure the best possible performance of your equipment we carry out regular software updates to correct possible errors and/or adding new features. Therefore we advise you to always install the latest updates. **READ THE INTRUCTIONS + UPDATE HISTORY CAREFULLY!***

### **BT-NONABEAM**

The attached "GSD-file" should be programmed using the special "FIRMWARE UPDATER2" unit from our Briteq® brand. (order code: 4379)

Update instructions are included with the firmware updater.

### **UPDATE HISTORY**

#### **V1.01F (2018-04-03)**

Original firmware as used in pre-batch1.

#### **V1.02A (2018-05-22)**

Only to be used if you want to stick to the 1<sup>st</sup> version of the DMX-chart, otherwise we advise you to update to V1.03 or later.

- LED-refresh rate changed from 1.1kHz to 1.2kHz to ensure flicker-free TV-recordings in both 50Hz and 60HZ mains frequency areas.

#### **V1.03 (2018-06-12)**

We advise to install this update as it brings solutions for some known issues.

- Complete rework of the setup menu to make it very simple and intuitive
- Complete rework of the 3 DMX-charts to 13CH + 29CH + 45CH versions.

[WWW.BRITEQ-LIGHTING.COM](http://WWW.BRITEQ-LIGHTING.COM)

©2018