

FIRMWARE UPDATE INSTRUCTION + UPDATE HISTORY

*To assure the best possible performance of your equipment we carry out regular software updates to correct possible errors and/or adding new features. Therefore we advise you to always install the latest updates. **READ THE INTRUCTIONS + UPDATE HISTORY CAREFULLY!***

BT-NONABEAM

The attached "GSD-file" should be programmed using the special "FIRMWARE UPDATER2" unit from our Briteq® brand. (order code: 4379)

Update instructions are included with the firmware updater.

UPDATE HISTORY

V1.01F (2018-04-03)

Original firmware as used in pre-batch1.

V1.02A (2018-05-22)

Only to be used if you want to stick to the 1st version of the DMX-chart, otherwise we advise you to update to V1.03 or later.

- LED-refresh rate changed from 1.1kHz to 1.2kHz to ensure flicker-free TV-recordings in both 50Hz and 60HZ mains frequency areas.

V1.03 (2018-06-12)

We advise to install this update as it brings solutions for some known issues.

- Complete rework of the setup menu to make it very simple and intuitive
- Complete rework of the 3 DMX-charts to 13CH + 29CH + 45CH versions.

V1.04 (2020-04-27)

We advise to install this update as it is needed while installed on the BT-NONAMOVE:

- Improved RDM communication with BT-NONAMOVE
- Control panel blocked → settings + information via BT-NONAMOVE panel.

WWW.BRITEQ-LIGHTING.COM

©2018-2020